



1640 E. Francis St., Ontario, CA 91761, USA | P: 909.930.1300 | www.FealSuspension.com

Congratulations on the purchase of Feal 460 coilovers specifically set up for your vehicle.

IMPORTANT: PLEASE READ BEFORE INSTALLING

- Measure stock ride height before removing OEM suspension.
- Set ride height and tighten spring pre load collars. Use a hammer to tap the end of the spanner wrench to tighten locking collars.
- For gravel applications, set vehicle ride height to stock or up to 1" above stock.
- For tarmac applications, you can lower the vehicle up to 1" below stock.
- Do not remove the nitrogen fill bolt at the top of the shock reservoir.
- To tighten the top mount nut, reach through the spring and hold the shock shaft from spinning by hand while using an impact to tighten the top hat nut. We recommend tightening the top hat nut to 35 ft/lbs.